









## TERMINALS

Note: Terminal part number endings of 6-32, 8-32, 10-24, and 10-32 refer to terminal thread size

 E9-CT-PK	 E9-SS-PK	 E9-R-2-PK	 E9-SF-PK*	 E9-CT-TS 10-32*
 E9-RAC-PK	 E9-HS6-32-PK E9-HS10-32-PK	 E9-CT-BS 6-32-PK	 E9-SS-SOS-PK	 E9-ASS-PK
 E9-SX-1 10-32-PK*	 E9-ACT-PK	 E9-BS6-32-PK E9-BS10-32-PK	 E9-R-SOS-PK	 E9-AS-SOS-PK
 E9-SSN-PK	 E9-RSN-PK	 E9-ASN-PK	 E9-BSN-PK	 E9-ACT-BS 6-32-PK
 E9-DS-1-PK	 E9-FF-1-PK	 E9-CC-1-PK	 E9-XC-PK	 E9-R-1-PK
 E9-RX-4 6-32-PK** E9-RX-4 10-32**	 E9-RC-5-PK+	 E9-EBF-PK	 E9-AEBF-PK	 5/16" Long E9-B-10 10-32-PK
 E9-BS-12-PK*	 11/16" Long E9-B-11 10-32-PK	 E9-458-9 10-32**	 E9-TC-10**	 E9-ITN 8-32 E9-ITN 10-32+
 E9-HT-6-32-10PK E9-HT-8-32-10PK E9-HT-10-32-10PK				

\* Available only in kit E9-3500

\*\* Available only in kits E9-54 or E9-3500

+ Available only in kit E9-54